

VarioMax

Technical Instruction Manual

Slab formwork support



Product features

VarioMax is a lightweight and flexible support system for filigree slabs. The system consists of only three components: prop, double beam and slide-in beam. It convinces due to its low weight and simple handling and can be flexibly adapted to suit any building layout.

VarioMax beams can also be used as stringers for conventional slab formwork.

VarioMax is compatible with MEVA's props and shoring systems.

The calculations for VarioMax are based on DIN EN 12812:2008-12.

The telescopic double and slide-in aluminium beams are lightweight, able to withstand high loads, durable and thus have a longer service life than H20 girders. Thanks to powder coating, there is less concrete adhesion, making the beams easier to clean.

The integrated mounting spikes determine the prop spacing and thus the position of the props. The use of VarioMax makes it unnecessary to add extra props just to be on the safe side and saves time, material and thus costs. The reduction of the number of props by up to 50% results in a reduction of labour costs of up to 40%. Additional components such as forked prop heads can also be dispensed with. In the best case, the prop spacing is 2.82 m and only four props are needed for a total stringer length of 8.77 m.

Formwork components must be visually inspected for damage before use. Damaged formwork components must not be installed. VarioMax is installed in the sequence described in the following sections.

Abbreviations, measurements, figures and tables, etc.

The abbreviation VM is used for the VarioMax. DIN means Deutsche Industrie-Norm (German Industrial Standard). E DIN (E = Entwurf / draft) means that the DIN is in draft status and not yet approved. Any further abbreviations are explained where they are used for the first time.

TÜV means Technischer Überwachungsverein. This is the independent German organisation that tests the safety of technical installations, machinery and motor vehicles. If a product passes the test, it is permitted to carry the GS seal. GS stands for Geprüfte Sicherheit (approved safety).

Measurements: This manual uses the metric system, i.e. m (for metre), cm (for centimetre) and mm (for millimetre).

Non-defined dimensions are in cm.

The page numbers in this manual start with VM. The figures and tables are numbered per page. Depending on its product abbreviation, a cross reference in the text refers to a page, table or figure in this or in another manual. This is indicated by the product code with which the cross-reference begins.

Slab formwork support



Please note

This Technical Instruction Manual contains information, instructions and tips that describe how to use the MEVA equipment on the construction site in a proper, quick and economic way. Most examples shown are standard applications that will occur in practice most often. For more complicated or special applications not covered in this manual, please contact the MEVA experts for advice. They will help you without delay.

When using our products, the federal, state and local occupational health and safety regulations must be observed. Please observe the assembly instructions that your local contractor or employer has created for the site on which the MEVA equipment is used. Such instructions are intended to minimise site-specific risks and must contain the following details:

- The order in which all working steps including assembly and disassembly must be carried out
- The weight of the panels and other system parts
- The type and number of ties and braces as well as the distance between them
- The location, number and dimensions of working scaffolds including the working area and fall protection equipment required
- Attachment points for panel transport by crane. With regard to panel transport, please observe this manual. Any deviation will require structural verification.

Important: Generally, only well-maintained material may be used. Damaged parts must be replaced. Use only original MEVA spare parts for replacement.

Contents

Overview	4
The main VarioMax components.....	5
Beam combinations / overview of dimensions.....	6
Support variants	7
System installation	8
Connecting beams.....	9
Prop load – Supporting a filigree slab.....	10
Perm. prop loading EuMax Pro/EuMax 20 + MD props – Supporting a filigree slab.....	18
VarioMax as conventional slab formwork.....	20
Prop load – Supporting conventional slab formwork.....	21
Perm. prop loading EuMax Pro/EuMax 20 + MD props – Supporting conventional slab formwork.....	29
VarioMax as conventional slab formwork – Spacing of planking support beams.....	31
VarioMax as conventional slab formwork – Example application.....	32
Services	34
Product list	35

Slab formwork support

Overview

Filigree slab can be supported using three system components: the props and the double beams and the slide-in beams made of aluminium (Figures 4.1 and 4.2).

VarioMax beams can also be used as stringers for conventional slab formwork (see page VM-20 ff).

Unlike stringers made of wood (Fig. 4.3), VarioMax has mounting spikes that are firmly connected to the beams and determine the prop spacing of 220 or 170 cm (Figures 4.1 and 4.2).

Slide-in beams can be pushed into the double beams, thus allowing the formwork to be flexibly adapted to suit any building layout.

The low own weight of the beams of, on average, 6.2 kg per running metre, the system's simple handling and the optimised number of props significantly reduces the amount of work involved.




Fig. 4.1




Fig. 4.2 VarioMax

Fig. 4.3 Stringers made of wood

Installation example (Fig. 4.4):

80 EuMax props are required for a slab surface of 230 m² = 0.35 props/m².




Fig. 4.4

Slab formwork support

The main VarioMax components

VarioMax double beam,
aluminium, power-coated
RAL 3020 (Traffic red).

Two lengths:

→ 3.75 m (Fig. 5.1), as basic element, with two mounting spikes 2.20 m apart for props. The beam is symmetrical and can be extended at both ends using slide-in beams.

→ 2.40 m (Fig. 5.2), supplementary to double beam 375, prop spacing 1.70 m for thicker slabs.

VarioMax slide-in beam,
aluminium, power-coated
RAL 9010 (Pure white).

Two lengths:

→ 3.00 m (Fig. 5.3), with mounting spike for prop. The slide-in beam is inserted into the double beam and permits stepless adjustment of the formwork to suit any room size.

→ 2.25 m (Fig. 5.4), with mounting spike for prop. The slide-in beam is inserted into the double beam and permits stepless adjustment of the formwork to suit any room size.

→ The calculation of deflection is based on $l/300$.




Fig. 5.1




Fig. 5.2




Fig. 5.3




Fig. 5.4

Description	Ref. No.
VarioMax double beam	
375.....	29-217-10
240.....	29-217-20
VarioMax slide-in beam	
300.....	29-217-60
225.....	29-217-70


Perm. structural values	VarioMax double beam	VarioMax slide-in beam
Perm. bending moment (M_{perm})	16.96 kNm	7.71 kNm
Perm. lateral force (V_{perm})	41.99 kN	29.97 kN

Table 5.5 Structural values


Beam combinations / overview of dimensions

Overview of dimensions – Minimum/maximum extension


Double beam 375 + slide-in beam 300



Double beam 375 + slide-in beam 225



Double beam 240 + slide-in beam 225



Slab formwork support

Support variants

VarioMax can be supported by stand-alone EuMax Pro/EuMax props (Fig. 7.1), stand-alone MEP props as well as by the MT 60 shoring tower (Fig. 7.2) or the MEP shoring tower (Fig. 7.3).

Important

- For the maximum loading when supporting filigree slabs as a function of the beam combination, the slab thickness and the stringer spacing refer to tables VM-10 to 16.
- For the maximum loading when supporting conventional slab formwork as a function of the beam combination, the slab thickness and the stringer spacing refer to tables VM-21 to 27.
- When using stand-alone EuMax Pro/EuMax props, also observe the load charts VM-18 and -19.
- When using the MT 60 shoring tower, stand-alone MEP props and the MEP shoring tower, observe the respective Technical Instruction Manuals.
- When using third-party props, the loading must always be verified.




Fig. 7.2 MT 60 shoring tower




Fig. 7.1 Stand-alone EuMax Pro/EuMax prop




Fig. 7.3 MEP shoring tower

Description	Ref. No.
Tripod.....	29-905-50
Tripod 120.....	29-905-52
Prop MEP 300 with SAS.....	29-907-65
Prop MEP 450 with SAS.....	29-907-70
EuMax Pro 30/150.....	X22-0073
EuMax Pro 30/250.....	X22-0074
EuMax Pro 30/350.....	X22-0075
EuMax Pro 30/450.....	X22-0076
EuMax Pro 20/300.....	X22-0070
EuMax Pro 20/400.....	X22-0071
EuMax Pro 20/550.....	X22-0072
EuMax 30/150.....	29-907-46
EuMax 30/250.....	29-907-51
EuMax 30/350.....	29-907-61
EuMax 30/450.....	29-907-62
EuMax 20/300.....	29-907-36
EuMax 20/400.....	29-907-41
EuMax 20/550.....	29-907-45

Slab formwork support

System installation

Steps for the installation using stand-alone props

1. Mark out the stringer spacings on the ground according to the formwork plan or the specification.
2. Place the VarioMax beams, props and tripods in the individual rooms in the quantities required at a distance of approx. half a meter from the stringer marking.
3. Pull out the props to the required length and place them on the stringer marking using the tripods so that they are spaced out according to the mounting spikes of the VarioMax double beams.
4. Place the double beams on the props first and then insert the slide-in beams (Fig. 8.1). If a slide-in beam is located between two double beams, the slide-in beam's integrated mounting spike can be pushed up as far as the double beam's mounting plate. At the other end of the slide-in beam, the stop bolt defines the maximum prop spacing (Fig. 8.4).
5. Set the exact height using a levelling instrument, laser or measuring lath.




Fig. 8.1



Fig. 8.2



Fig. 8.3




Fig. 8.4

Important

→ When using the beam combination double beam 240 / slide-in beam 225, the slide-in beam can tip downwards due to gravity. This is prevented using the universal wailing or the clamping piece and wood (see page VM-9).

→ The maximum stringer spacings and directions defined in the slab layout plan must be adhered to.

Note

→ For the set-up using the MT 60 and MEP shoring towers, the respective Technical Instruction Manuals must also be observed.

Slab formwork support

Connecting beams

Rows of VarioMax beams to support filigree slabs are stiffened in the area of the props and thus secured against rotation. The stiffening must extend up to the wall. Two variants are possible.

→ Variant 1:

VarioMax aluminium universal wailing. It is secured in the groove of the beam using the two integrated hammer-head screws (Figures 9.1 to 9.3).

→ Length: 2.48 m

→ Field of application: Stringer spacing from 1.00 m bis 2.40 m.

→ Variant 2:

VarioMax clamping piece (Fig. 9.5). It is secured in the groove of the beam using the integrated hammer-head screw (Figures 9.4 to 9.7). Additional roof lath / plank of wood with a maximum thickness of 24 mm required.




Fig. 9.1




Fig. 9.2




Fig. 9.3




Fig. 9.4




Fig. 9.6




Fig. 9.7




Fig. 9.5

Description	Ref. No.
VarioMax universal wailing	29-217-90
VarioMax clamping piece.....	29-217-95


Slab formwork support

Prop load – Supporting a filigree slab

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Double beam at the slab edge – Maximum extension

Double beam 375 +
slide-in beam 300




VarioMax double beam 375 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	16.28	17.69	19.11	20.52	21.94	22.65	23.36	24.77	26.19	27.74	29.30	30.08	30.86	32.41	33.97	35.53
	1.10	17.91	19.46	21.02	22.58	24.13	24.91	25.69	27.25	28.81	30.52	32.23	33.09	33.94	35.66	37.37	39.08
	1.20	19.53	21.23	22.93	24.63	26.33	27.18	28.03	29.73	31.42	33.29	35.16	36.10	37.03	38.90		
	1.30	21.16	23.00	24.84	26.68	28.52	29.44	30.36	32.20	34.04	36.07	38.09	39.10				
	1.40	22.79	24.77	26.75	28.73	30.72	31.71	32.70	34.68	36.66	38.84						
	1.50	24.42	26.54	28.66	30.79	32.91	33.97	35.03	37.16	39.28							
	1.60	26.05	28.31	30.57	32.84	35.10	36.24	37.37	39.63								
	1.70	27.67	30.08	32.49	34.89	37.30	38.50	39.70									
	1.80	29.30	31.85	34.40	36.94	39.49											
	1.90	30.93	33.62	36.31	39.00												
	2.00	32.56	35.39	38.22													
	2.10	34.18	37.16														
	2.20	35.81	38.93														
2.30	37.44																
2.40	39.07																

Table 10.1

Double beam at the slab edge – Maximum extension

Double beam 375 +
slide-in beam 225



VarioMax double beam 375 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	13.54	14.71	15.89	17.07	18.24	18.83	19.42	20.60	21.77	23.07	24.36	25.01	25.66	26.95	28.25	29.54
	1.10	14.89	16.18	17.48	18.77	20.07	20.72	21.36	22.66	23.95	25.38	26.80	27.51	28.22	29.65	31.07	32.50
	1.20	16.24	17.66	19.07	20.48	21.89	22.60	23.30	24.72	26.13	27.68	29.24	30.01	30.79	32.34	33.90	35.45
	1.30	17.60	19.13	20.66	22.19	23.72	24.48	25.25	26.78	28.31	29.99	31.67	32.51	33.36	35.04	36.72	38.41
	1.40	18.95	20.60	22.25	23.89	25.54	26.36	27.19	28.84	30.48	32.30	34.11	35.02	35.92	37.73	39.55	
	1.50	20.30	22.07	23.83	25.60	27.37	28.25	29.13	30.90	32.66	34.60	36.55	37.52	38.49			
	1.60	21.66	23.54	25.42	27.31	29.19	30.13	31.07	32.96	34.84	36.91	38.98					
	1.70	23.01	25.01	27.01	29.01	31.01	32.01	33.01	35.02	37.02	39.22						
	1.80	24.36	26.48	28.60	30.72	32.84	33.90	34.96	37.08	39.19							
	1.90	25.72	27.95	30.19	32.43	34.66	35.78	36.90	39.14								
	2.00	27.07	29.43	31.78	34.13	36.49	37.66	38.84									
	2.10	28.42	30.90	33.37	35.84	38.31	39.55										
	2.20	29.78	32.37	34.96	37.55												
	2.30	31.13	33.84	36.55	39.25												
	2.40	32.49	35.31	38.13													
	2.50	33.84	36.78	39.72													
2.60	35.19	38.25															
2.70	36.55	39.72															
2.80	37.90																
2.90	39.25																

Table 10.2

Slab formwork support

Prop load – Supporting a filigree slab

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Double beam at the slab edge – Maximum extension

Double beam 240 +
slide-in beam 300




VarioMax double beam 240 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	14.67	15.94	17.22	18.49	19.77	20.41	21.05	22.32	23.60	25.00	26.40	27.10	27.81	29.21	30.61	32.02
	1.10	16.14	17.54	18.94	20.34	21.75	22.45	23.15	24.55	25.96	27.50	29.04	29.81	30.59			
	1.20	17.60	19.13	20.66	22.19	23.72	24.49	25.25	26.79	28.32	30.00	31.68					
	1.30	19.07	20.73	22.39	24.04	25.70	26.53	27.36	29.02	30.68							
	1.40	20.54	22.32	24.11	25.89	27.68	28.57	29.46	31.25								
	1.50	22.00	23.92	25.83	27.74	29.66	30.61	31.57									
	1.60	23.47	25.51	27.55	29.59	31.63											
	1.70	24.94	27.10	29.27	31.44												
	1.80	26.40	28.70	30.99													
	1.90	27.87	30.29														
	2.00	29.34	31.89														
2.10	30.80																

Table 11.1

Double beam at the slab edge – Maximum extension

Double beam 240 +
slide-in beam 225



VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	12.06	13.11	14.16	15.21	16.26	16.78	17.31	18.36	19.41	20.56	21.71	22.29	22.87	24.02	25.18	26.33
	1.10	13.27	14.42	15.58	16.73	17.89	18.46	19.04	20.19	21.35	22.62	23.89	24.52	25.16	26.42	27.69	28.96
	1.20	14.48	15.74	16.99	18.25	19.51	20.14	20.77	22.03	23.29	24.67	26.06	26.75	27.44	28.83	30.21	31.60
	1.30	15.68	17.05	18.41	19.77	21.14	21.82	22.50	23.86	25.23	26.73	28.23	28.98	29.73	31.23	32.73	34.23
	1.40	16.89	18.36	19.83	21.29	22.76	23.50	24.23	25.70	27.17	28.78	30.40	31.21	32.02	33.63	35.25	36.86
	1.50	18.10	19.67	21.24	22.82	24.39	25.18	25.96	27.54	29.11	30.84	32.57	33.44	34.30	36.03	37.76	39.49
	1.60	19.30	20.98	22.66	24.34	26.02	26.85	27.69	29.37	31.05	32.90	34.74	35.67	36.59	38.44		
	1.70	20.51	22.29	24.07	25.86	27.64	28.53	29.42	31.21	32.99	34.95	36.91	37.90	38.88			
	1.80	21.71	23.60	25.49	27.38	29.27	30.21	31.16	33.04	34.93	37.01	39.09					
	1.90	22.92	24.91	26.91	28.90	30.89	31.89	32.89	34.88	36.87	39.06						
	2.00	24.13	26.23	28.32	30.42	32.52	33.57	34.62	36.72	38.81							
	2.10	25.33	27.54	29.74	31.94	34.14	35.25	36.35	38.55								
	2.20	26.54	28.85	31.16	33.46	35.77	36.92	38.08									
	2.30	27.75	30.16	32.57	34.98	37.40	38.60	39.81									
	2.40	28.95	31.47	33.99	36.51	39.02											
	2.50	30.16	32.78	35.40	38.03												
	2.60	31.37	34.09	36.82	39.55												
	2.70	32.57	35.40	38.24													
	2.80	33.78	36.72	39.65													
2.90	34.98	38.03															
3.00	36.19	39.34															

Table 11.2


Slab formwork support

Prop load – Supporting a filigree slab

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Double beam at the slab edge – Extension 220 cm

Double beam 375 +
slide-in beam 300



		VarioMax double beam 375 + slide-in beam 300															
Slab thickness (cm)		16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42
Stringer spacing e (m)	1.00	13.95	15.16	16.38	17.59	18.80	19.41	20.01	21.23	22.44	23.77	25.11	25.78	26.44	27.78	29.11	30.45
	1.10	15.34	16.68	18.01	19.35	20.68	21.35	22.02	23.35	24.68	26.15	27.62	28.35	29.09	30.56	32.02	33.49
	1.20	16.74	18.20	19.65	21.11	22.56	23.29	24.02	25.47	26.93	28.53	30.13	30.93	31.73	33.33	34.93	36.54
	1.30	18.13	19.71	21.29	22.87	24.44	25.23	26.02	27.60	29.17	30.91	32.64	33.51	34.38	36.11	37.85	39.58
	1.40	19.53	21.23	22.93	24.62	26.32	27.17	28.02	29.72	31.42	33.28	35.15	36.09	37.02	38.89		
	1.50	20.92	22.74	24.56	26.38	28.20	29.11	30.02	31.84	33.66	35.66	37.66	38.66	39.67			
	1.60	22.32	24.26	26.20	28.14	30.08	31.05	32.02	33.96	35.90	38.04						
	1.70	23.71	25.78	27.84	29.90	31.96	32.99	34.02	36.09	38.15							
	1.80	25.11	27.29	29.48	31.66	33.84	34.93	36.03	38.21								
	1.90	26.50	28.81	31.11	33.42	35.72	36.88	38.03									
	2.00	27.90	30.33	32.75	35.18	37.60	38.82										
	2.10	29.29	31.84	34.39	36.94	39.48											
	2.20	30.69	33.36	36.03	38.69												
	2.30	32.08	34.87	37.66													
	2.40	33.48	36.39	39.30													
2.50	34.87	37.91															
2.60	36.27	39.42															
2.70	37.66																
2.80	39.06																

Table 12.1

Double beam at the slab edge – Extension 220 cm

Double beam 240 +
slide-in beam 300



		VarioMax double beam 240 + slide-in beam 300															
Slab thickness (cm)		16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42
Stringer spacing e (m)	1.00	12.49	13.58	14.67	15.75	16.84	17.38	17.93	19.01	20.10	21.30	22.49	23.09	23.69	24.88	26.08	27.27
	1.10	13.74	14.94	16.13	17.33	18.52	19.12	19.72	20.92	22.11	23.42	24.74	25.40	26.05	27.37	28.68	30.00
	1.20	14.99	16.30	17.60	18.91	20.21	20.86	21.51	22.82	24.12	25.55	26.99	27.71	28.42	29.86	31.29	32.73
	1.30	16.24	17.66	19.07	20.48	21.89	22.60	23.31	24.72	26.13	27.68	29.24	30.01	30.79	32.35	33.90	35.45
	1.40	17.49	19.01	20.53	22.06	23.58	24.34	25.10	26.62	28.14	29.81	31.49	32.32	33.16	34.83	36.51	38.18
	1.50	18.74	20.37	22.00	23.63	25.26	26.08	26.89	28.52	30.15	31.94	33.74	34.63	35.53	37.32	39.11	
	1.60	19.99	21.73	23.47	25.21	26.95	27.81	28.68	30.42	32.16	34.07	35.98	36.94	37.90	39.81		
	1.70	21.24	23.09	24.94	26.78	28.63	29.55	30.48	32.32	34.17	36.20	38.23	39.25				
	1.80	22.49	24.45	26.40	28.36	30.31	31.29	32.27	34.22	36.18	38.33						
	1.90	23.74	25.80	27.87	29.93	32.00	33.03	34.06	36.13	38.19							
	2.00	24.99	27.16	29.34	31.51	33.68	34.77	35.85	38.03								
	2.10	26.24	28.52	30.80	33.08	35.37	36.51	37.65	39.93								
	2.20	27.49	29.88	32.27	34.66	37.05	38.24	39.44									
	2.30	28.74	31.24	33.74	36.23	38.73	39.98										
	2.40	29.99	32.60	35.20	37.81												
2.50	31.24	33.95	36.67	39.39													
2.60	32.49	35.31	38.14														
2.70	33.74	36.67	39.60														
2.80	34.99	38.03															
2.90	36.23	39.39															
3.00	37.48																

Table 12.2


Slab formwork support

Prop load – Supporting a filigree slab

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Double beam at the slab edge – Extension 170 cm

Double beam 375 +
slide-in beam 225




VarioMax double beam 375 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	12.28	13.34	14.41	15.48	16.55	17.08	17.61	18.68	19.75	20.92	22.10	22.68	23.27	24.45	25.62	26.79
	1.10	13.50	14.68	15.85	17.03	18.20	18.79	19.38	20.55	21.72	23.02	24.31	24.95	25.60	26.89	28.18	29.47
	1.20	14.73	16.01	17.29	18.57	19.86	20.50	21.14	22.42	23.70	25.11	26.52	27.22	27.93	29.33	30.74	32.15
	1.30	15.96	17.35	18.73	20.12	21.51	22.20	22.90	24.29	25.67	27.20	28.73	29.49	30.25	31.78	33.31	34.83
	1.40	17.19	18.68	20.18	21.67	23.16	23.91	24.66	26.15	27.65	29.29	30.94	31.76	32.58	34.22	35.87	37.51
	1.50	18.41	20.02	21.62	23.22	24.82	25.62	26.42	28.02	29.62	31.38	33.15	34.03	34.91	36.67	38.43	
	1.60	19.64	21.35	23.06	24.77	26.47	27.33	28.18	29.89	31.60	33.48	35.36	36.30	37.23			
	1.70	20.87	22.68	24.50	26.31	28.13	29.04	29.94	31.76	33.57	35.57	37.57	38.56				
	1.80	22.10	24.02	25.94	27.86	29.78	30.74	31.70	33.63	35.55	37.66						
	1.90	23.32	25.35	27.38	29.41	31.44	32.45	33.47	35.49	37.52							
	2.00	24.55	26.69	28.82	30.96	33.09	34.16	35.23	37.36								
	2.10	25.78	28.02	30.26	32.51	34.75	35.87	36.99									
	2.20	27.01	29.36	31.70	34.05	36.40	37.58	38.75									
	2.30	28.24	30.69	33.15	35.60	38.06											
	2.40	29.46	32.03	34.59	37.15												
	2.50	30.69	33.36	36.03	38.70												
2.60	31.92	34.69	37.47														
2.70	33.15	36.03	38.91														
2.80	34.37	37.36															
2.90	35.60	38.70															
3.00	36.83																

Table 13.1

Double beam at the slab edge – Extension 170 cm

Double beam 240 +
slide-in beam 225



VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	9.60	10.43	11.27	12.10	12.93	13.35	13.77	14.60	15.44	16.36	17.27	17.73	18.19	19.11	20.03	20.95
	1.10	10.56	11.47	12.39	13.31	14.23	14.69	15.15	16.06	16.98	17.99	19.00	19.51	20.01	21.02	22.03	23.04
	1.20	11.52	12.52	13.52	14.52	15.52	16.02	16.52	17.52	18.53	19.63	20.73	21.28	21.83	22.93	24.03	25.14
	1.30	12.48	13.56	14.65	15.73	16.82	17.36	17.90	18.98	20.07	21.26	22.46	23.05	23.65	24.84	26.04	27.23
	1.40	13.44	14.60	15.77	16.94	18.11	18.69	19.28	20.45	21.61	22.90	24.18	24.83	25.47	26.75	28.04	29.32
	1.50	14.40	15.65	16.90	18.15	19.40	20.03	20.65	21.91	23.16	24.53	25.91	26.60	27.29	28.67	30.04	31.42
	1.60	15.35	16.69	18.03	19.36	20.70	21.36	22.03	23.37	24.70	26.17	27.64	28.37	29.11	30.58	32.04	
	1.70	16.31	17.73	19.15	20.57	21.99	22.70	23.41	24.83	26.25	27.81	29.37	30.15	30.93	32.49		
	1.80	17.27	18.78	20.28	21.78	23.28	24.03	24.78	26.29	27.79	29.44	31.09	31.92				
	1.90	18.23	19.82	21.40	22.99	24.58	25.37	26.16	27.75	29.33	31.08						
	2.00	19.19	20.86	22.53	24.20	25.87	26.70	27.54	29.21	30.88							
	2.10	20.15	21.91	23.66	25.41	27.16	28.04	28.92	30.67	32.42							
	2.20	21.11	22.95	24.78	26.62	28.46	29.37	30.29	32.13								
	2.30	22.07	23.99	25.91	27.83	29.75	30.71	31.67									
	2.40	23.03	25.04	27.04	29.04	31.04	32.04										
	2.50	23.99	26.08	28.16	30.25	32.34											
2.60	24.95	27.12	29.29	31.46													
2.70	25.91	28.16	30.42														
2.80	26.87	29.21	31.54														
2.90	27.83	30.25															
3.00	28.79	31.29															

Table 13.2


Slab formwork support

Prop load – Supporting a filigree slab

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Slide-in beam at the slab edge – Maximum extension

Double beam 375 +
slide-in beam 300



VarioMax double beam 375 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	17.37	18.88	20.39	21.90	23.41	24.16	24.92	26.43	27.94	29.60	31.26	32.09	32.92	34.58	36.24	37.90
	1.10	19.10	20.76	22.42	24.08	25.75	26.58	27.41	29.07	30.73	32.56	34.38	35.30	36.21	38.04	39.86	
	1.20	20.84	22.65	24.46	26.27	28.09	28.99	29.90	31.71	33.52	35.52	37.51	38.51	39.50			
	1.30	22.57	24.54	26.50	28.46	30.43	31.41	32.39	34.35	36.32	38.47						
	1.40	24.31	26.43	28.54	30.65	32.77	33.82	34.88	37.00	39.11							
	1.50	26.05	28.31	30.58	32.84	35.11	36.24	37.37	39.64								
	1.60	27.78	30.20	32.62	35.03	37.45	38.66	39.86									
	1.70	29.52	32.09	34.65	37.22	39.79											
	1.80	31.26	33.98	36.69	39.41												
	1.90	32.99	35.86	38.73													
	2.00	34.73	37.75														
	2.10	36.47	39.64														
	2.20	38.20															
2.30	39.94																

Table 14.1

Slide-in beam at the slab edge – Maximum extension

Double beam 375 +
slide-in beam 225



VarioMax double beam 375 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	14.05	15.27	16.49	17.71	18.93	19.54	20.15	21.38	22.60	23.94	25.29	25.96	26.63	27.97	29.32	30.66
	1.10	15.45	16.80	18.14	19.48	20.83	21.50	22.17	23.51	24.86	26.34	27.81	28.55	29.29	30.77	32.25	33.73
	1.20	16.86	18.32	19.79	21.25	22.72	23.45	24.19	25.65	27.12	28.73	30.34	31.15	31.95	33.57	35.18	36.79
	1.30	18.26	19.85	21.44	23.03	24.61	25.41	26.20	27.79	29.38	31.12	32.87	33.74	34.62	36.36	38.11	39.86
	1.40	19.67	21.38	23.09	24.80	26.51	27.36	28.22	29.93	31.64	33.52	35.40	36.34	37.28	39.16		
	1.50	21.07	22.90	24.74	26.57	28.40	29.32	30.23	32.06	33.90	35.91	37.93	38.94	39.94			
	1.60	22.48	24.43	26.38	28.34	30.29	31.27	32.25	34.20	36.16	38.31						
	1.70	23.88	25.96	28.03	30.11	32.19	33.22	34.26	36.34	38.42							
	1.80	25.29	27.48	29.68	31.88	34.08	35.18	36.28	38.48								
	1.90	26.69	29.01	31.33	33.65	35.97	37.13	38.29									
	2.00	28.09	30.54	32.98	35.42	37.87	39.09										
	2.10	29.50	32.06	34.63	37.19	39.76											
	2.20	30.90	33.59	36.28	38.97												
	2.30	32.31	35.12	37.93													
	2.40	33.71	36.65	39.58													
2.50	35.12	38.17															
2.60	36.52	39.70															
2.70	37.93																
2.80	39.33																

Table 14.2


Slab formwork support

Prop load – Supporting a filigree slab

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Slide-in beam at the slab edge – Maximum extension

Double beam 240 +
slide-in beam 225




VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	9.93	10.79	11.66	12.52	13.38	13.82	14.25	15.11	15.97	16.92	17.87	18.35	18.82	19.77	20.72	21.67
	1.10	10.92	11.87	12.82	13.77	14.72	15.20	15.67	16.62	17.57	18.62	19.66	20.18	20.71	21.75	22.80	23.84
	1.20	11.92	12.95	13.99	15.02	16.06	16.58	17.10	18.13	19.17	20.31	21.45	22.02	22.59	23.73	24.87	26.01
	1.30	12.91	14.03	15.15	16.28	17.40	17.96	18.52	19.64	20.77	22.00	23.24	23.85	24.47	25.71	26.94	28.18
	1.40	13.90	15.11	16.32	17.53	18.74	19.34	19.95	21.16	22.36	23.69	25.02	25.69	26.35	27.68	29.01	
	1.50	14.90	16.19	17.49	18.78	20.08	20.72	21.37	22.67	23.96	25.39	26.81	27.52	28.24			
	1.60	15.89	17.27	18.65	20.03	21.41	22.11	22.80	24.18	25.56	27.08	28.60	29.36				
	1.70	16.88	18.35	19.82	21.29	22.75	23.49	24.22	25.69	27.16	28.77						
	1.80	17.87	19.43	20.98	22.54	24.09	24.87	25.65	27.20	28.75							
	1.90	18.87	20.51	22.15	23.79	25.43	26.25	27.07	28.71								
	2.00	19.86	21.59	23.31	25.04	26.77	27.63	28.50									
	2.10	20.85	22.67	24.48	26.29	28.11	29.01										
	2.20	21.85	23.75	26.65	27.55	29.45											
	2.30	22.84	24.83	26.81	28.80												
	2.40	23.83	25.91	27.98													
2.50	24.83	26.98	29.14														
2.60	25.82	28.06															
2.70	26.81	29.14															
2.80	27.80																
2.90	28.80																

Table 15.1

Slide-in beam at the slab edge – Extension 220 cm

Double beam 375 +
slide-in beam 300



VarioMax double beam 375 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	16.08	17.48	18.87	20.27	21.67	22.37	23.07	24.47	25.86	27.40	28.94	29.71	30.48	32.01	33.55	35.09
	1.10	17.68	19.22	20.76	22.30	23.84	24.60	25.37	26.91	28.45	30.14	31.83	32.68	33.52	35.22	36.91	38.60
	1.20	19.29	20.97	22.65	24.33	26.00	26.84	27.68	29.36	31.04	32.88	34.73	35.65	36.57	38.42		
	1.30	20.90	22.72	24.53	26.35	28.17	29.08	29.99	31.80	33.62	35.62	37.62	38.62	39.62			
	1.40	22.51	24.47	26.42	28.38	30.34	31.32	32.29	34.25	36.21	38.36						
	1.50	24.12	26.21	28.31	30.41	32.50	33.55	34.60	36.70	38.79							
	1.60	25.72	27.96	30.20	32.43	34.67	35.79	36.91	39.14								
	1.70	27.33	29.71	32.08	34.46	36.84	38.03	39.21									
	1.80	28.94	31.46	33.97	36.49	39.00											
	1.90	30.55	33.20	35.86	38.51												
	2.00	32.15	34.95	37.75													
	2.10	33.76	36.70	39.63													
	2.20	35.37	38.45														
	2.30	36.98															
	2.40	38.58															

Table 15.2


Slab formwork support

Prop load – Supporting a filigree slab

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Slide-in beam at the slab edge – Extension 220 cm

Double beam 240 +
slide-in beam 300



VarioMax double beam 240 + slide-in beam 225																
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42
Stringer spacing e (m)	1.00	11.21	12.19	13.16	14.14	15.11	15.60	16.09	17.06							
	1.10	12.33	13.41	14.48	15.55	16.62	17.16									
	1.20	13.46	14.63	15.80	16.97											
	1.30	14.58	15.84	17.11												
	1.40	15.70	17.06													
1.50	16.82															

Table 16.1

Slide-in beam at the slab edge – Extension 170 cm

Double beam 375 +
slide-in beam 225



VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	14.27	15.51	16.75	17.99	19.24	19.86	20.48	21.72	22.96	24.32	25.69	26.37	27.05	28.42	29.78	31.15
	1.10	15.70	17.06	18.43	19.79	21.16	21.84	22.52	23.89	25.25	26.76	28.26	29.01	29.76	31.26	32.76	34.26
	1.20	17.13	18.62	20.10	21.59	23.08	23.83	24.57	26.06	27.55	29.19	30.83	31.65	32.46	34.10	35.74	37.38
	1.30	18.55	20.17	21.78	23.39	25.01	25.81	26.62	28.23	29.85	31.62	33.40	34.28	35.17	36.94	38.72	
	1.40	19.98	21.72	23.45	25.19	26.93	27.80	28.67	30.40	32.14	34.05	35.96	36.92	37.88	39.79		
	1.50	21.41	23.27	25.13	26.99	28.85	29.78	30.71	32.58	34.44	36.49	38.53	39.56				
	1.60	22.83	24.82	26.81	28.79	30.78	31.77	32.76	34.75	36.73	38.92						
	1.70	24.26	26.37	28.48	30.59	32.70	33.76	34.81	36.92	39.03							
	1.80	25.69	27.92	30.16	32.39	34.62	35.74	36.86	39.09								
	1.90	27.12	29.47	31.83	34.19	36.55	37.73	38.91									
	2.00	28.54	31.03	33.51	35.99	38.47	39.71										
	2.10	29.97	32.58	35.18	37.79												
	2.20	31.40	34.13	36.86	39.59												
	2.30	32.82	35.68	38.53													
	2.40	34.25	37.23														
2.50	35.68	38.78															
2.60	37.11																
2.70	38.53																
2.80	39.96																

Table 16.2


Slab formwork support

Prop load – Supporting a filigree slab

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Slide-in beam at the slab edge – Extension 170 cm

Double beam 240 +
slide-in beam 225



VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	9.78	10.63	11.48	12.33	13.18	13.60	14.03	14.88	15.73	16.66	17.60	18.06	18.53	19.47	20.40	21.34
	1.10	10.75	11.69	12.62	13.56	14.49	14.96	15.43	16.36	17.30	18.33	19.35	19.87	20.38	21.41	22.44	23.47
	1.20	11.73	12.75	13.77	14.79	15.81	16.32	16.83	17.85	18.87	19.99	21.11	21.68	22.24	23.36	24.48	25.60
	1.30	12.71	13.81	14.92	16.02	17.13	17.68	18.23	19.34	20.44	21.66	22.87	23.48	24.09	25.30	26.52	27.74
	1.40	13.69	14.88	16.07	17.26	18.45	19.04	19.64	20.83	22.02	23.32	24.63	25.29	25.94	27.25	28.56	29.87
	1.50	14.66	15.94	17.21	18.49	19.76	20.40	21.04	22.31	23.59	24.99	26.39	27.09	27.80	29.20	30.60	32.00
	1.60	15.64	17.00	18.36	19.72	21.08	21.76	22.44	23.80	25.16	26.66	28.15	28.90	29.65	31.14		
	1.70	16.62	18.06	19.51	20.95	22.40	23.12	23.84	25.29	26.73	28.32	29.91	30.71	31.50			
	1.80	17.60	19.13	20.66	22.19	23.72	24.48	25.25	26.78	28.31	29.99	31.67					
	1.90	18.57	20.19	21.80	23.42	25.03	25.84	26.65	28.26	29.88	31.65						
	2.00	19.55	21.25	22.95	24.65	26.35	27.20	28.05	29.75	31.45							
	2.10	20.53	22.31	24.10	25.88	27.67	28.56	29.45	31.24								
	2.20	21.51	23.38	25.25	27.12	28.99	29.92	30.86									
	2.30	22.48	24.44	26.39	28.35	30.30	31.28										
	2.40	23.46	25.50	27.54	29.58	31.62											
	2.50	24.44	26.56	28.69	30.81												
2.60	25.42	27.63	29.84	32.05													
2.70	26.39	28.69	30.98														
2.80	27.37	29.75															
2.90	28.35	30.81															
3.00	29.33	31.88															

Table 17.1

Slab formwork support

Perm. prop loading EuMax Pro/EuMax 20 + MD props – Supporting a filigree slab

Slab height / buckling length of prop (m)	EuMax Pro/EuMax 20/300 + MD 300/20	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
3.00	20.60	23.60
2.90	22.10	25.80
2.80	23.80	27.90
2.70	25.60	30.30
2.60	27.60	32.70
2.50	29.30	34.20
2.40	30.50	35.80
2.30	32.20	37.30
2.20	34.20	38.50
2.10	36.80	39.40
2.00	39.80	39.80
1.90	39.80	39.80
1.80	39.80	39.80

Table 18.1

Slab height / buckling length of prop (m)	EuMax Pro/EuMax 20/550	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom
5.50	21.80	23.90
5.40	22.90	25.30
5.30	24.10	26.70
5.20	25.20	28.10
5.10	26.50	29.60
5.00	27.80	31.30
4.90	29.20	33.00
4.80	30.70	35.00
4.70	32.40	37.20
4.60	34.10	39.50
4.50	36.00	41.30
4.40	38.00	41.30
4.30	40.20	41.30
4.20	41.30	41.30
4.10	41.30	41.30
4.00	41.30	41.30
3.90	41.30	41.30
3.80	41.30	41.30
3.70	41.30	41.30
3.60	41.30	41.30
3.50	41.30	41.30
3.40	41.30	41.30
3.30	41.30	41.30
3.20	41.30	41.30
3.10	41.30	41.30
3.04	41.30	41.30

Table 18.3

Slab height / buckling length of prop (m)	EuMax Pro/EuMax 20/400 + MD 400/20	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom
4.00	21.20	25.00
3.90	22.40	26.80
3.80	23.80	28.80
3.70	25.30	31.10
3.60	26.80	33.60
3.50	28.50	36.30
3.40	30.30	37.00
3.30	32.00	37.00
3.20	33.00	37.00
3.10	34.20	37.00
3.00	35.60	37.00
2.90	37.00	37.00
2.80	37.00	37.00
2.70	37.00	37.00
2.60	37.00	37.00
2.50	37.00	37.00
2.40	37.00	37.00
2.34	37.00	37.00

Table 18.2




Fig. 18.4

Note:

The slab heights specified in the Tables 18.1 to 18.3 are made up of the extended length of the prop plus the height of the VarioMax beam = buckling length of the prop (Fig. 18.4). This means:

- ➔ Extended length of the prop under VarioMax double beam = slab height (in m) - 0.17 m
- ➔ Extended length of the prop under VarioMax slide-in beam = slab height (in m) - 0.16 m

Slab formwork support

Perm. prop loading EuMax Pro/EuMax 30 + ME props – Supporting a filigree slab

Slab height / buckling length of prop (m)	EuMax Pro/EuMax 30/250	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
2.50	47.00	47.00
2.40	47.00	47.00
2.30	47.00	47.00
2.20	47.00	47.00
2.10	47.00	47.00
2.00	47.00	47.00
1.90	47.00	47.00
1.80	47.00	47.00
1.70	47.00	47.00
1.60	47.00	47.00
1.54	47.00	47.00

Table 19.1

Slab height / buckling length of prop (m)	ME 250/30	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
2.50	31.60	37.10
2.40	34.60	41.80
2.30	37.80	46.20
2.20	39.90	46.20
2.10	41.50	46.20
2.00	43.00	46.20
1.90	44.80	46.20
1.80	46.20	46.20
1.70	46.20	46.20
1.60	46.20	46.20
1.54	46.20	46.20

Table 19.2

Slab height / buckling length of prop (m)	EuMax Pro/EuMax 30/350 + ME 350/30	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
3.50	31.20	33.40
3.40	33.60	36.20
3.30	36.20	39.20
3.20	38.80	42.10
3.10	41.80	43.80
3.00	44.00	45.30
2.90	45.30	47.00
2.80	47.00	47.00
2.70	47.00	47.00
2.60	47.00	47.00
2.50	47.00	47.00
2.40	47.00	47.00
2.30	47.00	47.00
2.20	47.00	47.00
2.10	47.00	47.00
2.04	47.00	47.00

Table 19.3

Slab height / buckling length of prop (m)	EuMax Pro/EuMax 30/450	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
4.50	31.50	34.30
4.40	33.50	36.70
4.30	35.50	39.30
4.20	37.80	41.30
4.10	40.10	41.30
4.00	41.30	41.30
3.90	41.30	41.30
3.80	41.30	41.30
3.70	41.30	41.30
3.60	41.30	41.30
3.50	41.30	41.30
3.40	41.30	41.30
3.30	41.30	41.30
3.20	41.30	41.30
3.10	41.30	41.30
3.00	41.30	41.30
2.90	41.30	41.30
2.80	41.30	41.30
2.70	41.30	41.30
2.60	41.30	41.30
2.54	41.30	41.30

Table 19.4

Note:

The slab heights specified in the Tables 19.1 to 19.4 are made up of the extended length of the prop plus the height of the VarioMax beam = buckling length of the prop (see page VM Fig. 18.4). This means:

- ➔ Extended length of the prop under VarioMax double beam = slab height (in m) - 0.17 m
- ➔ Extended length of the prop under VarioMax slide-in beam = slab height (in m) - 0.16 m

Slab formwork support

VarioMax as conventional slab formwork

VarioMax beams can be used as stringers for conventional slab formwork (Fig. 20.1).

Formwork girders H20 are used as planking support beams.

Formwork girders H20 can be secured to the VarioMax double beam by the wedging action of the VarioMax beam clamp H20 (Figures 20.2 and 20.3).




Fig. 20.1





Fig. 20.2

Fig. 20.3




Fig. 20.4

Description	Ref. No.
VarioMax beam clamp H20.....	29-217-96

Slab formwork support

Prop load – Supporting conventional slab formwork

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Double beam at the slab edge – Maximum extension

Double beam 375 +
slide-in beam 300




VarioMax double beam 375 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	16.86	18.27	19.69	21.11	22.52	23.23	23.94	25.36	26.77	28.33	29.89	30.67	31.45	33.00	34.56	36.12
	1.10	18.54	20.10	21.66	23.22	24.77	25.55	26.33	27.89	29.45	31.16	32.88	33.73	34.59	36.30	38.02	39.73
	1.20	20.23	21.93	23.63	25.33	27.03	27.88	28.73	30.43	32.13	34.00	35.87	36.80	37.74	39.61		
	1.30	21.91	23.75	25.60	27.44	29.28	30.20	31.12	32.96	34.80	36.83	38.85	39.87				
	1.40	23.60	25.58	27.57	29.55	31.53	32.52	33.51	35.50	37.48	39.66						
	1.50	25.28	27.41	29.53	31.66	33.78	34.85	35.91	38.03								
	1.60	26.97	29.24	31.50	33.77	36.04	37.17	38.30									
	1.70	28.66	31.06	33.47	35.88	38.29	39.49										
	1.80	30.34	32.89	35.44	37.99												
	1.90	32.03	34.72	37.41													
	2.00	33.71	36.55	39.38													
	2.10	35.40	38.37														
	2.20	37.08															
2.30	38.77																

Table 21.1

Double beam at the slab edge – Maximum extension

Double beam 375 +
slide-in beam 225



VarioMax double beam 375 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	14.01	15.19	16.37	17.54	18.72	19.31	19.90	21.08	22.25	23.55	24.85	25.49	26.14	27.44	28.73	30.03
	1.10	15.41	16.71	18.00	19.30	20.59	21.24	21.89	23.18	24.48	25.91	27.33	28.04	28.75	30.18	31.60	33.03
	1.20	16.81	18.23	19.64	21.05	22.47	23.17	23.88	25.29	26.71	28.26	29.81	30.59	31.37	32.92	34.48	36.03
	1.30	18.22	19.75	21.28	22.81	24.34	25.10	25.87	27.40	28.93	30.62	32.30	33.14	33.98	35.67	37.35	39.03
	1.40	19.62	21.27	22.91	24.56	26.21	27.04	27.86	29.51	31.16	32.97	34.78	35.69	36.60	38.41		
	1.50	21.02	22.78	24.55	26.32	28.08	28.97	29.85	31.62	33.38	35.33	37.27	38.24	39.21			
	1.60	22.42	24.30	26.19	28.07	29.96	30.90	31.84	33.72	35.61	37.68	39.75					
	1.70	23.82	25.82	27.82	29.83	31.83	32.83	33.83	35.83	37.83							
	1.80	25.22	27.34	29.46	31.58	33.70	34.76	35.82	37.94								
	1.90	26.62	28.86	31.10	33.34	35.57	36.69	37.81									
	2.00	28.02	30.38	32.73	35.09	37.44	38.62	39.80									
	2.10	29.43	31.90	34.37	36.84	39.32											
	2.20	30.83	33.42	36.01	38.60												
	2.30	32.23	34.94	37.64													
	2.40	33.63	36.46	39.28													
	2.50	35.03	37.97														
2.60	36.43	39.49															
2.70	37.83																
2.80	39.23																

Table 21.2


Slab formwork support

Prop load – Supporting conventional slab formwork

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Double beam at the slab edge – Maximum extension

Double beam 240 +
slide-in beam 300




VarioMax double beam 240 + slide-in beam 300																
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42
Stringer spacing e (m)	1.00	15.18	16.45	17.73	19.00	20.28	20.92	21.56	22.83	24.11	25.51	26.91	27.61	28.32	29.72	31.12
	1.10	16.70	18.10	19.50	20.91	22.31	23.01	23.71	25.11	26.52	28.06	29.60	30.38	31.15		
	1.20	18.21	19.74	21.28	22.81	24.34	25.10	25.87	27.40	28.93	30.61	32.30				
	1.30	19.73	21.39	23.05	24.71	26.36	27.19	28.02	29.68	31.34						
	1.40	21.25	23.04	24.82	26.61	28.39	29.29	30.18	31.96							
	1.50	22.77	24.68	26.59	28.51	30.42	31.38	32.33								
	1.60	24.29	26.33	28.37	30.41	32.45										
	1.70	25.80	27.97	30.14	32.31											
	1.80	27.32	29.62	31.91												
	1.90	28.84	31.26													
2.00	30.36															
2.10	31.87															

Table 22.1

Double beam at the slab edge – Maximum extension

Double beam 240 +
slide-in beam 225



VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	12.50	13.55	14.60	15.65	16.70	17.22	17.75	18.80	19.85	21.00	22.16	22.73	23.31	24.47	25.62	26.78
	1.10	13.74	14.90	16.05	17.21	18.36	18.94	19.52	20.67	21.83	23.10	24.37	25.01	25.64	26.91	28.18	29.45
	1.20	14.99	16.25	17.51	18.77	20.03	20.66	21.29	22.55	23.81	25.20	26.59	27.28	27.97	29.36	30.74	32.13
	1.30	16.24	17.61	18.97	20.34	21.70	22.39	23.07	24.43	25.80	27.30	28.80	29.55	30.30	31.80	33.31	34.81
	1.40	17.49	18.96	20.43	21.90	23.37	24.11	24.84	26.31	27.78	29.40	31.02	31.83	32.63	34.25	35.87	37.49
	1.50	18.74	20.32	21.89	23.47	25.04	25.83	26.62	28.19	29.77	31.50	33.23	34.10	34.97	36.70	38.43	
	1.60	19.99	21.67	23.35	25.03	26.71	27.55	28.39	30.07	31.75	33.60	35.45	36.37	37.30	39.14		
	1.70	21.24	23.03	24.81	26.60	28.38	29.27	30.17	31.95	33.74	35.70	37.66	38.65	39.63			
	1.80	22.49	24.38	26.27	28.16	30.05	31.00	31.94	33.83	35.72	37.80	39.88					
	1.90	23.74	25.74	27.73	29.73	31.72	32.72	33.72	35.71	37.71	39.90						
	2.00	24.99	27.09	29.19	31.29	33.39	34.44	35.49	37.59	39.69							
	2.10	26.24	28.44	30.65	32.85	35.06	36.16	37.26	39.47								
	2.20	27.49	29.80	32.11	34.42	36.73	37.88	39.04									
	2.30	28.74	31.15	33.57	35.98	38.40	39.61										
	2.40	29.99	32.51	35.03	37.55												
	2.50	31.24	33.86	36.49	39.11												
	2.60	32.49	35.22	37.95													
2.70	33.74	36.57	39.41														
2.80	34.99	37.93															
2.90	36.24	39.28															
3.00	37.49																

Table 22.2


Slab formwork support

Prop load – Supporting conventional slab formwork

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Double beam at the slab edge – Extension 220 cm

Double beam 375 +
slide-in beam 300



VarioMax double beam 375 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	14.45	15.66	16.87	18.09	19.30	19.91	20.52	21.73	22.94	24.28	25.62	26.28	26.95	28.29	29.62	30.96
	1.10	15.89	17.23	18.56	19.90	21.23	21.90	22.57	23.90	25.24	26.71	28.18	28.91	29.65	31.11	32.58	34.05
	1.20	17.34	18.79	20.25	21.71	23.16	23.89	24.62	26.08	27.53	29.14	30.74	31.54	32.34	33.94	35.55	37.15
	1.30	18.78	20.36	21.94	23.52	25.09	25.88	26.67	28.25	29.83	31.56	33.30	34.17	35.04	36.77	38.51	
	1.40	20.23	21.92	23.62	25.32	27.02	27.87	28.72	30.42	32.12	33.99	35.86	36.80	37.73	39.60		
	1.50	21.67	23.49	25.31	27.13	28.95	29.86	30.77	32.60	34.42	36.42	38.42	39.42				
	1.60	23.11	25.06	27.00	28.94	30.88	31.86	32.83	34.77	36.71	38.85						
	1.70	24.56	26.62	28.69	30.75	32.81	33.85	34.88	36.94	39.01							
	1.80	26.00	28.19	30.37	32.56	34.74	35.84	36.93	39.12								
	1.90	27.45	29.76	32.06	34.37	36.67	37.83	38.98									
	2.00	28.89	31.32	33.75	36.18	38.61	39.82										
	2.10	30.34	32.89	35.44	37.99												
	2.20	31.78	34.45	37.12	39.79												
	2.30	33.23	36.02	38.81													
2.40	34.67	37.59															
2.50	36.12	39.15															
2.60	37.56																
2.70	39.01																

Table 23.1

Double beam at the slab edge – Extension 220 cm

Double beam 240 +
slide-in beam 300



VarioMax double beam 240 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	12.93	14.02	15.10	16.19	17.28	17.82	18.36	19.45	20.53	21.73	22.93	23.52	24.12	25.32	26.51	27.71
	1.10	14.22	15.42	16.61	17.81	19.00	19.60	20.20	21.39	22.59	23.90	25.22	25.87	26.53	27.85	29.16	30.48
	1.20	15.52	16.82	18.12	19.43	20.73	21.38	22.03	23.34	24.64	26.08	27.51	28.23	28.94	30.38	31.81	33.25
	1.30	16.81	18.22	19.63	21.05	22.46	23.16	23.87	25.28	26.70	28.25	29.80	30.58	31.36	32.91	34.46	36.02
	1.40	18.10	19.62	21.14	22.66	24.19	24.95	25.71	27.23	28.75	30.42	32.10	32.93	33.77	35.44	37.11	38.79
	1.50	19.39	21.02	22.65	24.28	25.91	26.73	27.54	29.17	30.80	32.60	34.39	35.28	36.18	37.97	39.77	
	1.60	20.69	22.43	24.16	25.90	27.64	28.51	29.38	31.12	32.86	34.77	36.68	37.64	38.59			
	1.70	21.98	23.83	25.67	27.52	29.37	30.29	31.22	33.06	34.91	36.94	38.97	39.99				
	1.80	23.27	25.23	27.18	29.14	31.10	32.07	33.05	35.01	36.96	39.11						
	1.90	24.57	26.63	28.69	30.76	32.82	33.86	34.89	36.95	39.02							
	2.00	25.86	28.03	30.20	32.38	34.55	35.64	36.72	38.90								
	2.10	27.15	29.43	31.71	34.00	36.28	37.42	38.56									
	2.20	28.44	30.83	33.23	35.62	38.01	39.20										
	2.30	29.74	32.24	34.74	37.23	39.73											
	2.40	31.03	33.64	36.25	38.85												
	2.50	32.32	35.04	37.76													
	2.60	33.62	36.44	39.27													
2.70	34.91	37.84															
2.80	36.20	39.24															
2.90	37.50																
3.00	38.79																

Table 23.2


Slab formwork support

Prop load – Supporting conventional slab formwork

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Double beam at the slab edge – Extension 170 cm

Double beam 375 +
slide-in beam 225




VarioMax double beam 375 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	12.72	13.78	14.85	15.92	16.99	17.52	18.06	19.13	20.19	21.37	22.55	23.13	23.72	24.90	26.07	27.25
	1.10	13.99	15.16	16.34	17.51	18.69	19.28	19.86	21.04	22.21	23.51	24.80	25.45	26.09	27.39	28.68	29.97
	1.20	15.26	16.54	17.82	19.10	20.39	21.03	21.67	22.95	24.23	25.64	27.05	27.76	28.46	29.88	31.29	32.70
	1.30	16.53	17.92	19.31	20.70	22.09	22.78	23.47	24.86	26.25	27.78	29.31	30.07	30.84	32.36	33.89	35.42
	1.40	17.80	19.30	20.79	22.29	23.78	24.53	25.28	26.78	28.27	29.92	31.56	32.39	33.21	34.85	36.50	38.15
	1.50	19.07	20.68	22.28	23.88	25.48	26.29	27.09	28.69	30.29	32.06	33.82	34.70	35.58	37.34	39.11	
	1.60	20.34	22.05	23.76	25.47	27.18	28.04	28.89	30.60	32.31	34.19	36.07	37.01	37.95	39.83		
	1.70	21.62	23.43	25.25	27.07	28.88	29.79	30.70	32.51	34.33	36.33	38.33	39.33				
	1.80	22.89	24.81	26.73	28.66	30.58	31.54	32.50	34.43	36.35	38.47						
	1.90	24.16	26.19	28.22	30.25	32.28	33.29	34.31	36.34	38.37							
	2.00	25.43	27.57	29.70	31.84	33.98	35.05	36.12	38.25								
	2.10	26.70	28.95	31.19	33.43	35.68	36.80	37.92									
	2.20	27.97	30.32	32.67	35.03	37.38	38.55	39.73									
	2.30	29.24	31.70	34.16	36.62	39.08											
	2.40	30.52	33.08	35.65	38.21												
	2.50	31.79	34.46	37.13	39.80												
2.60	33.06	35.84	38.62														
2.70	34.33	37.22															
2.80	35.60	38.59															
2.90	36.87	39.97															
3.00	38.15																

Table 24.1

Double beam at the slab edge – Extension 170 cm

Double beam 240 +
slide-in beam 225




VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	9.93	10.77	11.60	12.43	13.27	13.69	14.10	14.94	15.77	16.69	17.61	18.07	18.53	19.44	20.36	21.28
	1.10	10.92	11.84	12.76	13.68	14.60	15.05	15.51	16.43	17.35	18.36	19.37	19.87	20.38	21.39	22.40	23.41
	1.20	11.92	12.92	13.92	14.92	15.92	16.42	16.92	17.93	18.93	20.03	21.13	21.68	22.23	23.33	24.43	25.54
	1.30	12.91	13.99	15.08	16.16	17.25	17.79	18.33	19.42	20.50	21.70	22.89	23.49	24.08	25.28	26.47	27.66
	1.40	13.90	15.07	16.24	17.41	18.58	19.16	19.74	20.91	22.08	23.37	24.65	25.29	25.94	27.22	28.51	29.79
	1.50	14.90	16.15	17.40	18.65	19.90	20.53	21.15	22.41	23.66	25.04	26.41	27.10	27.79	29.17	30.54	31.92
	1.60	15.89	17.22	18.56	19.89	21.23	21.90	22.56	23.90	25.24	26.70	28.17	28.91	29.64	31.11	32.58	
	1.70	16.88	18.30	19.72	21.14	22.56	23.27	23.98	25.39	26.81	28.37	29.93	30.71	31.49			
	1.80	17.87	19.38	20.88	22.38	23.88	24.63	25.39	26.89	28.39	30.04	31.69	32.52				
	1.90	18.87	20.45	22.04	23.62	25.21	26.00	26.80	28.38	29.97	31.71						
	2.00	19.86	21.53	23.20	24.87	26.54	27.37	28.21	29.88	31.54							
	2.10	20.85	22.61	24.36	26.11	27.86	28.74	29.62	31.37								
	2.20	21.85	23.68	25.52	27.35	29.19	30.11	31.03									
	2.30	22.84	24.76	26.68	28.60	30.52	31.48	32.44									
	2.40	23.83	25.84	27.84	29.84	31.84											
	2.50	24.83	26.91	29.00	31.09												
2.60	25.82	27.99	30.16	32.33													
2.70	26.81	29.07	31.32														
2.80	27.81	30.14	32.48														
2.90	28.80	31.22															
3.00	29.79	32.30															

Table 24.2

Prop load – Supporting conventional slab formwork

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Slide-in beam at the slab edge – Maximum extension

 Double beam 375 +
slide-in beam 300


VarioMax double beam 375 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	18.00	19.52	21.03	22.54	24.06	24.81	25.57	27.08	28.60	30.26	31.92	32.76	33.59	35.25	36.92	38.58
	1.10	19.81	21.47	23.13	24.80	26.46	27.29	28.13	29.79	31.46	33.29	35.12	36.03	36.95	38.78		
	1.20	21.61	23.42	25.24	27.05	28.87	29.78	30.68	32.50	34.31	36.31	38.31	39.31				
	1.30	23.41	25.37	27.34	29.31	31.27	32.26	33.24	35.21	37.17	39.34						
	1.40	25.21	27.32	29.44	31.56	33.68	34.74	35.80	37.92								
	1.50	27.01	29.28	31.55	33.82	36.09	37.22	38.35									
	1.60	28.81	31.23	33.65	36.07	38.49	39.70										
	1.70	30.61	33.18	35.75	38.32												
	1.80	32.41	35.13	37.86													
	1.90	34.21	37.08	39.96													
	2.00	36.01	39.04														
2.10	37.81																
2.20	39.61																

Table 25.1

Slide-in beam at the slab edge – Maximum extension

 Double beam 375 +
slide-in beam 225


VarioMax double beam 375 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	14.57	15.79	17.01	18.24	19.46	20.07	20.69	21.91	23.13	24.48	25.83	26.50	27.17	28.52	29.87	31.21
	1.10	16.02	17.37	18.71	20.06	21.41	22.08	22.75	24.10	25.45	26.93	28.41	29.15	29.89	31.37	32.85	34.33
	1.20	17.48	18.95	20.42	21.89	23.35	24.09	24.82	26.29	27.76	29.38	30.99	31.80	32.61	34.22	35.84	37.45
	1.30	18.94	20.53	22.12	23.71	25.30	26.10	26.89	28.48	30.07	31.82	33.57	34.45	35.32	37.07	38.83	
	1.40	20.39	22.11	23.82	25.53	27.25	28.10	28.96	30.67	32.39	34.27	36.16	37.10	38.04	39.93		
	1.50	21.85	23.68	25.52	27.36	29.19	30.11	31.03	32.86	34.70	36.72	38.74	39.75				
	1.60	23.30	25.26	27.22	29.18	31.14	32.12	33.10	35.06	37.01	39.17						
	1.70	24.76	26.84	28.92	31.00	33.08	34.13	35.17	37.25	39.33							
	1.80	26.22	28.42	30.62	32.83	35.03	36.13	37.23	39.44								
	1.90	27.67	30.00	32.33	34.65	36.98	38.14	39.30									
	2.00	29.13	31.58	34.03	36.48	38.92											
	2.10	30.59	33.16	35.73	38.30												
	2.20	32.04	34.74	37.43													
	2.30	33.50	36.32	39.13													
	2.40	34.96	37.90														
2.50	36.41	39.47															
2.60	37.87																
2.70	39.33																

Table 25.2


Slab formwork support

Prop load – Supporting conventional slab formwork

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Slide-in beam at the slab edge – Maximum extension

Double beam 240 +
slide-in beam 225



VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	10.28	11.14	12.00	12.87	13.73	14.16	14.59	15.46	16.32	17.27	18.22	18.69	19.17	20.12	21.07	22.02
	1.10	11.30	12.25	13.20	14.15	15.10	15.58	16.05	17.00	17.95	19.00	20.04	20.56	21.09	22.13	23.18	24.22
	1.20	12.33	13.37	14.40	15.44	16.48	16.99	17.51	18.55	19.58	20.72	21.86	22.43	23.00	24.14	25.28	26.42
	1.30	13.36	14.48	15.60	16.73	17.85	18.41	18.97	20.09	21.22	22.45	23.69	24.30	24.92	26.16	27.39	28.63
	1.40	14.39	15.59	16.80	18.01	19.22	19.83	20.43	21.64	22.85	24.18	25.51	26.17	26.84	28.17	29.50	
	1.50	15.41	16.71	18.00	19.30	20.59	21.24	21.89	23.18	24.48	25.91	27.33	28.04	28.75			
	1.60	16.44	17.82	19.20	20.59	21.97	22.66	23.35	24.73	26.11	27.63	29.15					
	1.70	17.47	18.94	20.40	21.87	23.34	24.07	24.81	26.28	27.74	29.36						
	1.80	18.50	20.05	21.60	23.16	24.71	25.49	26.27	27.82	29.38							
	1.90	19.52	21.16	22.81	24.45	26.09	26.91	27.73	29.37								
	2.00	20.55	22.28	24.01	25.73	27.46	28.32	29.19									
	2.10	21.58	23.39	25.21	27.02	28.83											
	2.20	22.61	24.51	26.41	28.31												
	2.30	23.63	25.62	27.61	29.59												
	2.40	24.66	26.73	28.81													
2.50	25.69	27.85															
2.60	26.72	28.96															
2.70	27.74																
2.80	28.77																

Table 26.1

Slide-in beam at the slab edge – Extension 220 cm

Double beam 375 +
slide-in beam 300



VarioMax double beam 375 + slide-in beam 300																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	16.67	18.07	19.47	20.87	22.27	22.97	23.67	25.07	26.47	28.01	29.55	30.32	31.09	32.63	34.17	35.71
	1.10	18.33	19.87	21.41	22.95	24.49	25.27	26.04	27.58	29.12	30.81	32.51	33.35	34.20	35.89	37.59	39.28
	1.20	20.00	21.68	23.36	25.04	26.72	27.56	28.40	30.08	31.76	33.61	35.46	36.38	37.31	39.16		
	1.30	21.67	23.49	25.31	27.13	28.95	29.86	30.77	32.59	34.41	36.41	38.42	39.42				
	1.40	23.33	25.29	27.25	29.21	31.18	32.16	33.14	35.10	37.06	39.21						
	1.50	25.00	27.10	29.20	31.30	33.40	34.45	35.50	37.60	39.70							
	1.60	26.67	28.91	31.15	33.39	35.63	36.75	37.87									
	1.70	28.33	30.71	33.09	35.47	37.86	39.05										
	1.80	30.00	32.52	35.04	37.56												
	1.90	31.67	34.33	36.99	39.65												
	2.00	33.33	36.13	38.93													
	2.10	35.00	37.94														
	2.20	36.67	39.75														
	2.30	38.33															
	2.40	40.00															

Table 26.2


Slab formwork support

Prop load – Supporting conventional slab formwork

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Slide-in beam at the slab edge – Extension 220 cm

Double beam 240 +
slide-in beam 300



VarioMax double beam 240 + slide-in beam 300																
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42
Stringer spacing e (m)	1.00	11.60	12.58	13.55	14.53	15.50	15.99	16.48	17.45							
	1.10	12.76	13.84	14.91	15.98	17.05	17.59									
	1.20	13.92	15.09	16.26	17.43											
	1.30	15.08	16.35	17.62												
	1.40	16.24	17.61													
	1.50	17.40														

Table 27.1

Slide-in beam at the slab edge – Extension 170 cm

Double beam 375 +
slide-in beam 225



VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	14.80	16.05	17.29	18.54	19.78	20.40	21.02	22.27	23.51	24.88	26.25	26.93	27.62	28.99	30.35	31.72
	1.10	16.28	17.65	19.02	20.39	21.76	22.44	23.13	24.49	25.86	27.37	28.87	29.63	30.38	31.88	33.39	34.89
	1.20	17.76	19.26	20.75	22.24	23.74	24.48	25.23	26.72	28.21	29.86	31.50	32.32	33.14	34.78	36.42	38.07
	1.30	19.24	20.86	22.48	24.10	25.71	26.52	27.33	28.95	30.57	32.34	34.12	35.01	35.90	37.68	39.46	
	1.40	20.73	22.47	24.21	25.95	27.69	28.56	29.43	31.17	32.92	34.83	36.75	37.71	38.66			
	1.50	22.21	24.07	25.94	27.80	29.67	30.60	31.54	33.40	35.27	37.32	39.37					
	1.60	23.69	25.68	27.67	29.66	31.65	32.64	33.64	35.63	37.62	39.81						
	1.70	25.17	27.28	29.40	31.51	33.63	34.68	35.74	37.85	39.97							
	1.80	26.65	28.89	31.12	33.36	35.60	36.72	37.84									
	1.90	28.13	30.49	32.85	35.22	37.58	38.76	39.94									
	2.00	29.61	32.10	34.58	37.07	39.56											
	2.10	31.09	33.70	36.31	38.92												
	2.20	32.57	35.30	38.04													
	2.30	34.05	36.91	39.77													
	2.40	35.53	38.51														
2.50	37.01																
2.60	38.49																
2.70	39.97																


Table 27.2

Slab formwork support

Prop load – Supporting conventional slab formwork

Prop load as a function of the beam combination, the slab thickness and the stringer spacing in kN/prop

Slide-in beam at the slab edge – Extension 170 cm

 Double beam 240 +
slide-in beam 225


VarioMax double beam 240 + slide-in beam 225																	
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42	
Stringer spacing e (m)	1.00	10.12	10.97	11.82	12.67	13.52	13.94	14.37	15.22	16.07	17.00	17.94	18.40	18.87	19.81	20.74	21.68
	1.10	11.13	12.06	13.00	13.93	14.87	15.33	15.80	16.74	17.67	18.70	19.73	20.24	20.76	21.79	22.81	23.84
	1.20	12.14	13.16	14.18	15.20	16.22	16.73	17.24	18.26	19.28	20.40	21.52	22.08	22.64	23.77	24.89	26.01
	1.30	13.15	14.25	15.36	16.46	17.57	18.12	18.67	19.78	20.88	22.10	23.32	23.92	24.53	25.75	26.96	28.18
	1.40	14.16	15.35	16.54	17.73	18.92	19.52	20.11	21.30	22.49	23.80	25.11	25.76	26.42	27.73	29.04	30.35
	1.50	15.17	16.45	17.72	19.00	20.27	20.91	21.55	22.82	24.10	25.50	26.90	27.60	28.31	29.71	31.11	
	1.60	16.18	17.54	18.90	20.26	21.62	22.30	22.98	24.34	25.70	27.20	28.70	29.44	30.19	31.69		
	1.70	17.20	18.64	20.09	21.53	22.98	23.70	24.42	25.87	27.31	28.90	30.49	31.28	32.08			
	1.80	18.21	19.74	21.27	22.80	24.33	25.09	25.86	27.39	28.92	30.60						
	1.90	19.22	20.83	22.45	24.06	25.68	26.49	27.29	28.91	30.52							
	2.00	20.23	21.93	23.63	25.33	27.03	27.88	28.73	30.43								
	2.10	21.24	23.03	24.81	26.60	28.38	29.27	30.17	31.95								
	2.20	22.25	24.12	25.99	27.86	29.73	30.67	31.60									
	2.30	23.26	25.22	27.17	29.13	31.08	32.06										
	2.40	24.28	26.32	28.36	30.40												
	2.50	25.29	27.41	29.54	31.66												
	2.60	26.30	28.51	30.72													
2.70	27.31	29.61	31.90														
2.80	28.32	30.70															
2.90	29.33	31.80															
3.00	30.35																

Table 28.1

Perm. prop loading EuMax Pro/EuMax 20 + MD props – Supporting conventional slab formwork

Buckling length of prop (m)	EuMax Pro/EuMax 20/300 + MD 300/20	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
3.00	20.60	23.60
2.90	22.10	25.80
2.80	23.80	27.90
2.70	25.60	30.30
2.60	27.60	32.70
2.50	29.30	34.20
2.40	30.50	35.80
2.30	32.20	37.30
2.20	34.20	38.50
2.10	36.80	39.40
2.00	39.80	39.80
1.90	39.80	39.80
1.80	39.80	39.80

Buckling length of prop (m)	EuMax Pro/EuMax 20/400 + MD 400/20	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom
4.00	21.20	25.00
3.90	22.40	26.80
3.80	23.80	28.80
3.70	25.30	31.10
3.60	26.80	33.60
3.50	28.50	36.30
3.40	30.30	37.00
3.30	32.00	37.00
3.20	33.00	37.00
3.10	34.20	37.00
3.00	35.60	37.00
2.90	37.00	37.00
2.80	37.00	37.00
2.70	37.00	37.00
2.60	37.00	37.00
2.50	37.00	37.00
2.40	37.00	37.00
2.34	37.00	37.00

Table 29.1

Buckling length of prop (m)	EuMax Pro/EuMax 20/550	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom
5.50	21.80	23.90
5.40	22.90	25.30
5.30	24.10	26.70
5.20	25.20	28.10
5.10	26.50	29.60
5.00	27.80	31.30
4.90	29.20	33.00
4.80	30.70	35.00
4.70	32.40	37.20
4.60	34.10	39.50
4.50	36.00	41.30
4.40	38.00	41.30
4.30	40.20	41.30
4.20	41.30	41.30
4.10	41.30	41.30
4.00	41.30	41.30
3.90	41.30	41.30
3.80	41.30	41.30
3.70	41.30	41.30
3.60	41.30	41.30
3.50	41.30	41.30
3.40	41.30	41.30
3.30	41.30	41.30
3.20	41.30	41.30
3.10	41.30	41.30
3.04	41.30	41.30

Table 29.3

Table 29.2




Fig. 29.4

Note:

The buckling lengths specified in the Tables 29.1 to 29.3 are made up of the extended length of the prop plus the height of the VarioMax beam. The slab height is made up of the buckling length of the prop plus the height of the formwork girder H20 including the facing (Fig. 29.4).

- Extended length of the prop under VarioMax double beam = slab height (in m) - 0.391 m
- Extended length of the prop under VarioMax slide-in beam = slab height (in m) - 0.381 m

Slab formwork support

Perm. prop loading EuMax Pro/EuMax 30 + ME props – Supporting conventional slab formwork

Buckling length of prop (m)	EuMax Pro/EuMax 30/250	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
2.50	47.00	47.00
2.40	47.00	47.00
2.30	47.00	47.00
2.20	47.00	47.00
2.10	47.00	47.00
2.00	47.00	47.00
1.90	47.00	47.00
1.80	47.00	47.00
1.70	47.00	47.00
1.60	47.00	47.00
1.54	47.00	47.00

Table 30.1

Buckling length of prop (m)	ME 250/30	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
2.50	31.60	37.10
2.40	34.60	41.80
2.30	37.80	46.20
2.20	39.90	46.20
2.10	41.50	46.20
2.00	43.00	46.20
1.90	44.80	46.20
1.80	46.20	46.20
1.70	46.20	46.20
1.60	46.20	46.20
1.54	46.20	46.20

Table 30.2

Buckling length of prop (m)	EuMax Pro/EuMax 30/350 + ME 350/30	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
3.50	31.20	33.40
3.40	33.60	36.20
3.30	36.20	39.20
3.20	38.80	42.10
3.10	41.80	43.80
3.00	44.00	45.30
2.90	45.30	47.00
2.80	47.00	47.00
2.70	47.00	47.00
2.60	47.00	47.00
2.50	47.00	47.00
2.40	47.00	47.00
2.30	47.00	47.00
2.20	47.00	47.00
2.10	47.00	47.00
2.04	47.00	47.00

Table 30.3

Buckling length of prop (m)	EuMax Pro/EuMax 30/450	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
4.50	31.50	34.30
4.40	33.50	36.70
4.30	35.50	39.30
4.20	37.80	41.30
4.10	40.10	41.30
4.00	41.30	41.30
3.90	41.30	41.30
3.80	41.30	41.30
3.70	41.30	41.30
3.60	41.30	41.30
3.50	41.30	41.30
3.40	41.30	41.30
3.30	41.30	41.30
3.20	41.30	41.30
3.10	41.30	41.30
3.00	41.30	41.30
2.90	41.30	41.30
2.80	41.30	41.30
2.70	41.30	41.30
2.60	41.30	41.30
2.54	41.30	41.30

Table 30.4

Note:

The buckling lengths specified in the Tables 30.1 to 30.4 are made up of the extended length of the prop plus the height of the VarioMax beam. The slab height is made up of the buckling length of the prop plus the height of the formwork girder H20 including the facing (see page VM Fig. 29.4). This means:

- Extended length of the prop under VarioMax double beam = slab height (in m) - 0.391 m
- Extended length of the prop under VarioMax slide-in beam = slab height (in m) - 0.381 m

VarioMax as conventional slab formwork – Spacing of planking support beams

Using Table 31.1, it is possible to calculate the spacing (distance between centre lines) of the planking support beams as a function of the slab thickness.

The VarioMax stringer combination (see pages VM-21 to 28) can be selected on the basis of:

- desired props with their specific maximum loading, or
- desired VarioMax beam lengths.

For further slab thicknesses please contact our application engineering department.

Maximum spacing between planking support beams for a 21 mm thick facing (determining element is the facing)

Slab thickness (cm)	Loading for facing (kN/m ²)	Spacing of planking support beams (distance between centre lines) (m)
16	5.63	0.693
18	6.13	0.667
20	6.63	0.645
22	7.13	0.625
24	7.63	0.607
25	7.88	0.599
26	8.13	0.592
28	8.63	0.578
30	9.13	0.565
32	9.68	0.553
34	10.23	0.542
35	10.50	0.537
36	10.78	0.532
38	11.33	0.522
40	11.88	0.514
42	12.43	0.505

Table 31.1

Slab formwork support


VarioMax as conventional slab formwork – Example application

Example application 1

Requirement: Slab thickness: 0.18 m
 Slab height: 2.95 m
 Use of EuMax Pro/EuMax 20/300 prop

Buckling length of prop = slab height - planking support beam including facing = 2.95 m - 0.221 m = 2.729 m
 Perm. prop loading for buckling length 2.729 m (2.80 m): 23.8 kN (irrespective of the installation position)

Selected: VarioMax beam combination: double beam 375 + slide-in beam 300, max. extension, double beam at the slab edge
 Prop loading for slab thickness 0.18 m and stringer spacing 1.30 m = 23.75 kN < 23.8 kN
 Max. spacing of planking support beams for slab thickness 0.18 m = 0.667 m



Buckling length of prop (m)	EuMax Pro/EuMax 20/300 + MD 300/20	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
3.00	20.60	23.60
2.90	22.10	25.80
2.80	23.80	27.90
2.70	25.60	30.30
2.60	27.60	32.70
2.50	29.30	34.20
2.40	30.50	35.80
2.30	32.20	37.30
2.20	34.20	38.50
2.10	36.80	39.40
2.00	39.80	39.80
1.90	39.80	39.80
1.80	39.80	39.80


Slab thickness (cm)	Loading for facing (kN/m ²)	Spacing of planking support beams (distance between centre lines) (m)
16	5.63	0.693
18	6.13	0.667
20	6.63	0.645
22	7.13	0.625
24	7.63	0.607
25	7.88	0.599
26	8.13	0.592
28	8.63	0.578
30	9.13	0.565
32	9.68	0.553
34	10.23	0.542
35	10.50	0.537
36	10.78	0.532
38	11.33	0.522
40	11.88	0.514
42	12.43	0.505

Fig. 32.1

Tab. 32.1

Double beam at the slab edge – Maximum extension

Double beam 375 + slide-in beam 300



VarioMax double beam 375 + slide-in beam 300																
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42
1.00	16.86	18.27	19.69	21.11	22.52	23.23	23.94	25.36	26.77	28.33	29.89	30.67	31.45	33.00	34.56	36.12
1.10	18.54	20.10	21.66	23.22	24.77	25.55	26.33	27.89	29.45	31.16	32.88	33.73	34.59	36.30	38.02	39.73
1.20	20.23	21.93	23.63	25.33	27.03	27.88	28.73	30.43	32.13	34.00	35.87	36.80	37.74	39.61		
1.30	21.91	23.75	25.60	27.44	29.28	30.20	31.12	32.96	34.80	36.83	38.85	39.87				
1.40	23.60	25.58	27.57	29.55	31.53	32.52	33.51	35.50	37.48	39.66						
1.50	25.28	27.41	29.53	31.66	33.78	34.85	35.91	38.03								
1.60	26.97	29.24	31.50	33.77	36.04	37.17	38.30									
1.70	28.66	31.06	33.47	35.88	38.29	39.49										
1.80	30.34	32.89	35.44	37.99												
1.90	32.03	34.72	37.41													
2.00	33.71	36.55	39.38													
2.10	35.40	38.37														
2.20	37.08															
2.30	38.77															

Tab. 32.2

Slab formwork support

VarioMax as conventional slab formwork – Example application

Example application 2

Requirement: Slab thickness: 0.34 m
 Slab height: 3.40 m

Use of VarioMax beam combination: double beam 240 + slide-in beam 225, max. extension, double beam at the slab edge

Loading on prop for slab thickness 0.34 m and stringer spacing 1.80 m = 39.88 kN

Selected: EuMax Pro/EuMax 30/350 prop


Buckling length of prop = slab height - planking support beam including facing = 3.40 m - 0.221 m = 3.179 m

Perm. prop loading for buckling length 3.179 m (3.20 m): 42.10 kN (inner tube at the bottom) > 39.88 kN

Max. spacing of planking support beams for slab thickness 0.34 m = 0.542 m

Double beam at the slab edge – Maximum extension

Double beam 240 +
 slide-in beam 225



VarioMax double beam 240 + slide-in beam 225																		
Slab thickness (cm)	16	18	20	22	24	25	26	28	30	32	34	35	36	38	40	42		
Stringer spacing e (m)	1.00	12.50	13.55	14.60	15.65	16.70	17.22	17.75	18.80	19.85	21.00	22.16	22.73	23.31	24.47	25.62	26.78	
	1.10	13.74	14.90	16.05	17.21	18.36	18.94	19.52	20.67	21.83	23.10	24.37	25.01	25.64	26.91	28.18	29.45	
	1.20	14.99	16.25	17.51	18.77	20.03	20.66	21.29	22.55	23.81	25.20	26.59	27.28	27.97	29.36	30.74	32.13	
	1.30	16.24	17.61	18.97	20.34	21.70	22.39	23.07	24.43	25.80	27.30	28.80	29.55	30.30	31.80	33.31	34.81	
	1.40	17.49	18.96	20.43	21.90	23.37	24.11	24.84	26.31	27.78	29.40	31.02	31.83	32.63	34.25	35.87	37.49	
	1.50	18.74	20.32	21.89	23.47	25.04	25.83	26.62	28.19	29.77	31.50	33.23	34.10	34.97	36.70	38.43		
	1.60	19.99	21.67	23.35	25.03	26.71	27.55	28.39	30.07	31.75	33.60	35.45	36.37	37.30	39.14			
	1.70	21.24	23.03	24.81	26.60	28.38	29.27	30.17	31.95	33.74	35.70	37.66	38.65	39.63				
	1.80	22.49	24.38	26.27	28.16	30.05	31.00	31.94	33.83	35.72	37.80	39.88						
	1.90	23.74	25.74	27.73	29.73	31.72	32.72	33.72	35.71	37.71	39.90							
2.00	24.99	27.09	29.19	31.29	33.39	34.44	35.49	37.59	39.69									

Tab. 33.1




Fig. 33.1

Buckling length of prop (m)	EuMax Pro/EuMax 30/350 + ME 350/30	
	Perm. prop loading in kN	
	Inner tube at top	Inner tube at bottom*
3.50	31.20	33.40
3.40	33.30	36.20
3.30	36.20	39.20
3.20	38.80	42.10
3.10	41.80	43.80
3.00	44.00	45.30
2.90	45.30	47.00
2.80	47.00	47.00
2.70	47.00	47.00
2.60	47.00	47.00
2.50	47.00	47.00
2.40	47.00	47.00
2.30	47.00	47.00
2.20	47.00	47.00
2.10	47.00	47.00
2.04	47.00	47.00

Tab. 33.2

Slab thickness (cm)	Loading for facing (kN/m ²)	Spacing of planking support beams (distance between centre lines) (m)
16	5.63	0.693
18	6.13	0.667
20	6.63	0.645
22	7.13	0.625
24	7.63	0.607
25	7.88	0.599
26	8.13	0.592
28	8.63	0.578
30	9.13	0.565
32	9.68	0.553
34	10.23	0.542
35	10.50	0.537
36	10.78	0.532
38	11.33	0.522
40	11.88	0.514
42	12.43	0.505

Tab. 33.3

Slab formwork support

Services

Cleaning

The components of the VarioMax system are cleaned professionally using industrial equipment upon return.

Reconditioning of wall formwork and other components

Reconditioning is carried out as follows: The frames are checked and, if necessary, blasted, coated with a high-quality cured powder coating, and provided with a new facing. As long as the formwork equipment still has its full load capacity, correct dimensions and is fully functional, reconditioning will always be a more economical solution than purchasing new formwork. Please note that the cleaning and reconditioning service is not available in all countries in which MEVA does business.

Rentals

As we have a comprehensive range of equipment in stock, we offer our customers the option of renting supplementary material at peak times. The MEVA logistics centre guarantees rapid delivery throughout Europe. We also give prospective customers the chance to test MEVA formwork so they can see its benefits for themselves in actual use.

RentalPlus

For a flat-rate fee MEVA's "fully comprehensive insurance" for rental formwork and equipment covers all secondary costs that occur after return (excludes losses and write-offs). For the customer this means: Costing certainty instead of additional charges, an earlier end of the rental period and thus lower rental costs because you save the time required for cleaning and repairs.

Formwork drawings

Our application engineers worldwide work with CAD systems. This ensures that you always receive optimum formwork solutions and practice-oriented formwork and work cycle plans.

Special solutions

We can help with special parts, custom-designed for your project, to supplement our standard formwork systems.

Structural calculations

Generally, this is only necessary for applications such as single-sided formwork where the anchor parts are embedded in the foundation or the base slab. On request, we can perform structural calculations for such applications at an additional charge.

Formwork seminars

To ensure that all our products are used properly and efficiently, we offer formwork seminars. They provide our customers with a good opportunity to keep themselves up to date and to benefit from the know-how of our engineers.

